4

consumed credits variable;

CLAIMS

We Claim:

1	1. A method of transmitting and receiving messages in a network,
2	comprising:
3	transmitting a flow control message header to a transmitting node from a
4	receiving node, wherein the flow control header comprises a message sent field and
5	a message limit field;
6	transmitting a message from the transmitting node to the receiving node and
7	incrementing a send counter;
8	receiving the message by the receiving node and incrementing a consumed
9	credits variable;
10	determining a message was dropped when the message sent field is less than
11	or equal to the value of the consumed credits variable;
12	adjusting the message limit field to compensate for the dropped message; and
13	transmitting the message limit field to the transmitting node.
1	2. The method recited in claim 1, wherein the determining a message was
2	dropped further comprises:

setting a variable drop count equal to the message sent field less the

5	determining if the variable drop count is less than an available credits variable,
6	wherein the available credits variable represents the total amount of space allocated
7	to receive messages from a particular node; and
В	increasing the message limit field value and transmitting the flow control
9	message header to the transmitting node.

- 1 3. The method recited in claim 2, further comprising:
- 2 setting a new credits variable equal to the available credits variable plus the
- 3 new credits; and
- 4 setting the available credits variable to zero.
- 1 4. The method recited in claim 3, further comprising:
- 2 setting a send limit variable equal to the message limit field; and
- 3 executing a threshold module.
- 1 5. The method recited in claim 4, wherein the threshold module further
- 2 comprising:
- determining if the available credits variable is less than a credit threshold
- 4 variable; and
- 5 transmitting the flow control message header to the transmitting node.
- 1 6. The method recited in claim 1, further comprising:

3

4

1

2

4

5

6

7

8

9

1



transmitting at a predetermined time interval the flow control message header
to the transmitting node, wherein a value contained in the message limit field is
increased.

- 7. The method recited in claim 6, wherein the increase in the message limit field further comprises:
- 3 incrementing send counter and the message sent field;
 - incrementing and available credits variable by a new credits variable, wherein the available credits variable represents the total number of messages the transmitting node may send and the new credits variable represents additional messages that may be transmitted by the transmitting node; and
 - setting the message limit field equal to the consumed credits variable plus the available credits variable.
 - 8. The method recited in claim 1, further comprising:
- determining if a get credit variable is set to true, wherein the get credit variable represents that additional messages may be sent by the transmitting node to the receiving node; and
- incrementing the available credits variable by the number of additional messages permitted.

11

12

13

1

2

3

4

5

6

7

1	9. An apparatus comprising a data storage medium for storing instructions
2	when executed by a processor results in, comprising:
3	transmitting a flow control message header to a transmitting node from a
4	receiving node, wherein the flow control header comprises a message sent field and
5	a message limit field;
6	transmitting a message from the transmitting node to the receiving node and
7	incrementing a send counter;
8	receiving the message by the receiving node and incrementing a consumed
9	credits variable;

or equal to the value of the consumed credits variable;

10. The apparatus recited in claim 9, wherein the determining a message was dropped further comprises:

transmitting the message limit field to the transmitting node.

determining a message was dropped when the message sent field is less than

adjusting the message limit field to compensate for the dropped message; and

- setting a variable drop count equal to the message sent field less the consumed credits variable;
- determining if the variable drop count is less than an available credits variable, wherein the available credits variable represents the total amount of space allocated to receive messages from a particular node; and

8	increasing the message limit field value and transmitting the flow control
9	message header to the transmitting node.

- 1 11. The apparatus recited in claim 10, further comprising:
- 2 setting a new credits variable equal to the available credits variable plus the
- 3 new credits variable; and
- 4 setting the available credits variable to zero.
- 1 12. The apparatus recited in claim 11, further comprising:
- 2 setting a send limit variable equal to the message limit field; and
- 3 executing a threshold module.
- 1 **13.** The apparatus recited in claim 12, wherein the threshold module further
- 2 comprising:
- determining if the available credits variable is less than a credit threshold
- 4 variable; and
- 5 transmitting the flow control message header to the transmitting node.
- 1 **14.** The apparatus recited in claim 9, further comprising:
- 2 transmitting at a predetermined time interval the flow control message header
- 3 to the transmitting node, wherein a value contained in the message limit field is
- 4 increased.

5

1	15. The apparatus recited in claim 14, wherein the increase in the message
2	limit field further comprises:
3	incrementing send counter and the message sent field;
4	incrementing and available credits variable by a new credits variable, wherein
5	the available credits variable represents the total number of messages the
6	transmitting node may send and the new credits variable represents additional
7	messages that may be transmitted by the transmitting node; and
8	setting the message limit field equal to the consumed credits variable plus the
9	available credits variable.
1.	16. The apparatus recited in claim 9, further comprising:
1.	16. The apparatus recited in claim 9, further comprising: determining if a get credit variable is set to true, wherein the get credit variable
	, , , , , , , , , , , , , , , , , , , ,
2	determining if a get credit variable is set to true, wherein the get credit variable
2	determining if a get credit variable is set to true, wherein the get credit variable represents that additional messages may be sent by the transmitting node to the
2 3 4	determining if a get credit variable is set to true, wherein the get credit variable represents that additional messages may be sent by the transmitting node to the receiving node; and
2 3 4 5	determining if a get credit variable is set to true, wherein the get credit variable represents that additional messages may be sent by the transmitting node to the receiving node; and incrementing the available credits variable by the number of additional
2 3 4 5	determining if a get credit variable is set to true, wherein the get credit variable represents that additional messages may be sent by the transmitting node to the receiving node; and incrementing the available credits variable by the number of additional
2 3 4 5 6	determining if a get credit variable is set to true, wherein the get credit variable represents that additional messages may be sent by the transmitting node to the receiving node; and incrementing the available credits variable by the number of additional messages permitted.

received based upon a flow control header, wherein the flow control header

comprises a message sent field and a message limit field; and

7

8

1

2

3

1

2

3


1



- a post send module to update an available credits variable, wherein the available credits variable indicates the total number of messages a transmitting node may send to a receiving node.
- 18. The system recited in claim 17, wherein the receive done module increments a consumed credits variable and compares the consumed credits variable to the message sent field to determine if a message has been dropped.
 - The system recited in claim 18, wherein the receive done module will 19. add an additional value to the message limit field when it is determined that a message has been dropped.
- 20. The system recited in claim 19, further comprising: 1
- 2 a threshold check module to determine if the transmitting node has any 3 available credits remaining and updating the message limit field to include additional 4 credits when no further credits remaining for the transmitting node.
 - 21. The system recited in claim 19, further comprising:
- 2 a post receive module to increment a new credit variable and process pending 3 message requests.







- a periodic update module to determine at a predetermined time interval if a
- 3 transmitting node has run out of credits used to transmit messages with.